

MAG-DRO[®]

MITRE SLOT BASE


HOW TO ALIGN YOUR FENCE WITH YOUR MITER SLOT

REQUIRED

- MAG-DRO's Mitre Slot Base
- Six-inch calipers
- Painter's tape

STEPS

1. Mark two spots on your fence with tape to allow repeatable measurements. Place tape on the fence and then put a mark with a pen or pencil. Do this on each end of the fence several inches in from the end. You may need to adjust tape positions.



2. Place calipers in the Mitre Slot Base per the figure on the base. See instructions or tip on how to do this.



3. With the Mitre Slot Base in the table saw miter slot, move caliper and Mitre Slot Base to the mark closest to you. Move the depth probe until it touches the fence, and zero the calipers.
4. Retract the calipers, and then move the caliper and Mitre Slot Base to the mark away from you. Extend the depth probe until it touches the fence. The reading on the caliper is the distance the fence is out of alignment. If the number is positive, then the fence is farther away from the slot the far end. If the number is negative, then the fence is closer from the slot at the far end.

5. Adjust fence as directed in your table saw instruction manual. Re-measure after each adjustment.