

MAG-DRO®

INSTALLATION AND INTRODUCTION

Installation



1. Loosen thumbscrew
1 ½ turns



2. Slide caliper
under washer in
the orientation
of the image



3. Straighten
caliper on base
4. Tighten
thumbscrew

Adding directional arrows to your caliper (optional)



1. Cut out the arrows and signs
from instructions
2. Apply clear tape over arrows
3. Place arrows per instructions
and trim excess tape

Try it out and move your fence 0.005”



1. Place caliper and base
assembly in miter slot,
extend probe up against the
fence, and set the zero on
the calipers. (On a cam-locking
fence, place the unit close to
the front of the fence due to
movement when locking.)
2. If the gap is between the
miter slot and fence is too
large, use a board as a
spacer.
3. Loosen and move fence
while applying pressure to
the caliper to keep the
depth probe against the
fence. Lock fence when
adjusted correctly.